

NOVEMBER, 1920

REPAIR PART PRICE LIST

McWhorter Automatic Potato Planter



No. 1 McWhorter Automatic Potato Planter with Fertilizer Attachment

BATEMAN AND COMPANIES, INC.

347 MADISON AVENUE, NEW YORK CITY

Manufacturing Divisions

Bateman Mfg. Co., Grenloch, N. J.
Belcher & Taylor A. T. Co., Chicopee Falls, Mass.
The Gutaway Harrow Co., Higganum, Conn.
Duane H. Nash, Inc., Millington, N. J.
The Richardson Mfg. Co., Worcester, Mass.
The Bateman-Wilkinson Co., Ltd., Toronto,
Canada.

Distributing Sales Headquarters

Bateman and Companies, Inc., New York City.
Bateman and Companies, Inc., Grenloch, N. J.
Bateman and Companies, Inc., Chicopee
Falls, Mass.
Bateman and Companies, Inc., Worcester, Mass.
The Bateman-Wilkinson Co., Ltd., Toronto,
Canada.

Branch and Distributing Houses

Presque Isle, Me.
Burnham, Me.
Worcester, Mass.
Chicopee Falls, Mass.
Wallingford, Conn.
Higganum, Conn.
Canastota, N. Y.
Millington, N. J.

Grenloch, N. J.
Raleigh, N. C.
Columbia, S. C.
Savannah, Ga.
Atlanta, Ga.
Montgomery, Ala.
Mobile, Ala.
Orville, Ohio
Cincinnati, Ohio

Lansing, Mich.
Minneapolis, Minn.
Milwaukee, Wis.
Davenport, Ia.
Kansas City, Mo.
Memphis, Tenn.
New Orleans, La.
Jacksonville, Fla.
Houston, Texas

Denver, Colo.
Salt Lake City, Utah
Spokane, Wash.
Portland, Ore.
San Francisco, Calif.
Stockton, Calif.
Los Angeles, Calif.
Toronto, Canada

GENERAL FULL LINE EXHIBITION

Grand Central Palace :: 46th Street and Lexington Avenue

:: New York City

Form A12—Nov. '20



INSTRUCTIONS FOR ORDERING PARTS

WRITE your name and complete address plainly, also state where you wish the repairs shipped and how, either by Parcel Post, Express or Freight. Unless orders instruct us to insure goods, Parcel Post shipments are made at the customer's risk.

Give the number of the part wanted, also the name of the machine for which it is wanted.

If the part has no number, or it is defaced so it cannot be given, order by the description, always being sure to give the name of the machine for which it is wanted.

R. H. and L. H. means Right Hand and Left Hand. When designating Right Hand or Left Hand, stand facing the way the machine runs.

In case of doubt as to the correct name or description of part wanted, or if you do not find the part listed, it is advisable to send old parts, with transportation charges prepaid, to us to be duplicated. Be sure to tag each piece with your name and address and notify us by letter, explain-

ing just what you want, how you are sending the part, either by Parcel Post, Express or Freight. Also state if you wish old part returned to you.

PARTS CLAIMED DEFECTIVE

Under no circumstances will claims for defects be allowed unless parts claimed defective are returned, transportation charges prepaid, to the factory for our inspection.

When shipping parts for inspection, see that each piece is tagged with shipper's name and address, and advise us fully by letter.

In cases of declined claims the inspected parts are subject to the shipper's orders for disposition, and Bateman and Companies, Inc., cannot be responsible for such parts for more than 30 days, at the expiration of which they will be scrapped without credit to the shipper. Shippers accept these conditions when shipping parts.

Repair Parts for McWhorter Automatic Potato Planter

REPAIR PARTS	NO.	PRICE	WEIGHT LBS.	WEIGHT OZ.
18-Tooth Sprocket (half) for planting 16 inches apart.....	T 21	\$.65	1	2
16- " " " " 14 " "	T 22	.60	1	
Roller Slide for Opening Shoe.....	T 55	1.10	1	13
Collar Outside of Left Wheel.....	T 57	.25		6
Holder for Marker Chain, R. or L. H.....	T 60	.25		6
Holder for Marker Rod, R. or L. H.....	T 64	1.00	1	11
Roller of Main Chain Tightner.....	T110	.65	1	2
Collar on Right of Center.....	T235	.50		13
Ratchet that Works Potato Shute.....	T246	.65	1	3
Spring Fastener on Front Drag Bar.....	E 16	.20		4
Lock Casting for Marker Rod, R. or L. H.....	T258	.25		6
Part of Lower Potato Hopper, left rear.....	300	2.40	4	5
Base " " " under center.....	302	2.80	5	2
Potato Return Shute on right of center, rear part.....	303	1.70	3	2
Part of Lower Potato Hopper, left front.....	304	1.80	3	6
" " " " at end of Potato Shute.....	305	.40		11
" " " " at rear end.....	306	.25		6
Opening Plow, Right Side.....	308	1.15	2	3
" " " Left.....	309	2.70	5	
Cam Inside Center, Large.....	310	.35		9
Potato Return Shute at Right of Center, front part.....	314	.90	1	10
Ring Bearing, Inside of Center.....	316	1.70	2	15
Loose Piece in Center, R. H.....	317	.40		10
Double Sprocket for Main and Fertilizer Chains.....	318	3.00	5	8
Left Side of Center that Holds Pickers.....	320	4.60	8	1
Drag for Opening Shoe.....	323	5.70	10	8

Repair Parts for McWhorter Automatic Potato Planter

REPAIR PARTS	NO.	PRICE	WEIGHT LBS.	WEIGHT OZ.
Center Casting, R. H. Side	325	\$7.50	13	6
Box for Axle that Carries Center, R. or L. H.	326	1.05	1	12
Casting that Holds Tongue and Drag-Bar at Front of Frame	328	2.60	4	8
Picker Castings Complete	329 & 330	.70	1	4
Lever Latch Casting that Holds Rear End of Tongue	331	2.10	3	10
Throw Out of Gear Casting that Engages Sprocket	332	.60	1	
Latch for Throw Out of Gear Lever	333	.40		12
Spud that Holds Roller for Regulating Potatoes	334	.20		4
Roller that Regulates Potatoes	335	.30		8
14-Tooth Sprocket (half) for Planting 12 inches apart	337	.40		12
Casting on which Double-Trees sets Front of Frame	338	2.30	3	14
Throw Out of Gear Casting that Pushes Rod	339	.75	1	5
Tightner for Main Drive Chain	340	1.40	2	6
Land Side on Left of Plow	341	.55		15
Box for Front Disc	342	2.70	4	12
Hanger and Box for Rear Discs, R. or L. H.	343	3.40	6	2
Hub for Discs with Rivets	345	1.20	2	2
Clutch of Main Gear, Pinned to Axle	346	.65	1	1
Axle Box, L. H.	347	2.70	4	12
“ “ R. H.	348	2.90	5	
Part of Lower Potato Hopper, Right Rear	349	1.60	2	12
Guide for Back Disc Lift Chains, R. or L. H.	350	.50		13
Knee on Rear of Frame, R. H.	351	.60		15
“ “ “ L. H.	352	.60		15
Box in Center of Main Axle, Also Holds Gear Rod	353	3.80	6	5
Vibrator Under Potato Shute	355	1.00	1	11
Slotted Casting in Rear of Lower Potato Hopper	356	.55		14
Cam Inside Center, Small	357	.35		9
Holder for Marker Points, R. or L. H.	358	.75	1	6
Side of Lower Potato Shute, Left	359	1.30	2	5
“ “ “ Right	360	1.30	2	4
12-Tooth Sprocket (half) for Planting 10 inches apart	362	.40		10
Picker Complete	364 & 365	1.00	1	10
Scraper for Wheel, R. H.	366	1.60	2	10
“ “ L. H.	367	1.60	2	8
False Side to Opening Shoe	368	1.80	3	3
Collar on Drag Bar with Set Screw	369	.35		9
Side of Lower Potato Shute, Right	370	1.60	2	12
“ “ “ Left	371	2.10	3	11
Casting Midway on Tongue to Which Braces are Bolted With Set Screw	372	1.60	2	12
Drag Bars for Covering Discs, Right or Left		3.20	8	5
Cross		2.80	7	
Push Bars for Opening Plow, Right or Left		.75	1	14
Standards for Rear of Potato Hopper, Right or Left		.50	1	2
Brace, Top of Double-trees to Tongue		.50	1	1
Brace around Rear of Lower Potato Hopper		1.05	2	10
Lever, Right or Left Side		1.25	3	1
Braces, Top of Upper Potato Hopper, Right or Left		.30		11
Braces that Carry Drag Bars for Covering Discs		.80	2	
Tie Braces for Above		.30		13
V Braces for Frame		.30		13
Marker Points, Right or Left, each		.25		10
Adjusters for Covering Discs, Right or Left, each		.15		4
Brace that Carries Adjusting Roller		.15		4
Braces that Carry Lift Chain for Opening Plow, each		.15		4
Seat Standard when without Fertilizer Attachment		2.40	6	
Chain for Driving Potato Planter Parts		1.20	2	12
Chains for Lifting Back Discs (2) each		.35		13
Chain for Lifting Opening Shoe		.20		4
Chain for Throwing Out of Gear		.20		4
Chains for Regulating Depth of Back Discs (2), each		.15		2
Chains for Lifting Markers		.30		5
Spring on Main Axle		.40		7
Spring for Regulating Opening Plow		.80		15

Repair Parts for McWhorter Automatic Potato Planter

REPAIR PARTS	NO.	PRICE	WEIGHT LBS.	WEIGHT OZ.
Spring for Regulating Back Disc.		\$.50		9
Spring for Vibrating Shaker.		.20		2
Spring for Pickers.		.15		2
Discs, Rear (2), each.		1.40	4	
Disc, Front.		1.10	3	6
Discs, Rear, with Hub (2), each.		2.40	6	2
Disc, Front, with Hub.		2.10	5	8
Wheel, Right or Left Hand.		12.50	49	
Hub for Wheel, Right or Left Hand.		2.20	3	14
Axle, Main.		4.00	12	11
Axle for Pickers.		2.50	7	1
Shaft for Throwing Out of Gear.		.45		13
Marker Rods (2), each.		1.30	3	4
Rod for Lever Latch.		.20		2
Latch on Lever.		.20		2
Bolt that Goes Through T-55.		.15		4
Hinge for Potato Shaker.		.20		4
Seat.		2.00	3	12
Double-trees.		6.00	12	4
Neck-Yoke.		2.00	4	4
Tongue.		10.00	26	8
Angle Frame, Right or Left.		3.80	9	11
Angle Cross Frame, Rear.		1.40	3	6
“ “ “ Front.		.90	2	2

PARTS ON FERTILIZER DISTRIBUTER ATTACHMENT

Upper Belt Guide	D 8	.30	
" " "	D 9	.30	7
Holder for Feed Gate Spring	D 20	.20	4
Front L. H. Top Piece for Spout	D102	.15	3
Rear " " " " "	D103	.15	3
Front R. H. " " " "	D104	.15	3
Rear " " " " "	D105	.15	3
Agitator Finger	E 2	.30	7
" "	E 21	.30	7
Sprocket on Agitator Axle	E 26	1.20	2
Tightner for Agitator Chain	E 36	.20	4
Sprocket on End of Belt Axle for Driving Agitator Axle	E 40	.50	14
Feed Gate	T 28	1.05	12
Cover of Agitator Chain Inside of Fertilizer Hopper	T 49	1.50	2
Side Belt Guide, L. H.	T 93	.65	17
" " " R. H.	T 94	.65	17
Lower " "	T 95	.15	2
Bearing for Fertilizer Feed Belt Axle	T259	.45	12
Back Roller for Belt with Rivet and Cotter, R. or L. H.	T 97	.15	3
Sprocket that Drives Fertilizer Belt	T276	.55	14
Spout Frame	T283	2.00	3
Tightner for Fertilizer Feed Chain	361	.45	13
Front Roller Sprocket for Fertilizer Belt	T284	1.30	2
Rubber Spout for Fertilizer45	3
Bolt with Thumb Nut for Regulating T-2815	2
Chain for Driving Fertilizer Distributer50	14
Chain for Driving Agitator on Distributer35	9
Spring for Regulating Fertilizer Feed Gate15	1
Belt for Feeding Fertilizer		4.00	4
Axle for Fertilizer Belt80	2
Axle for Fertilizer Agitator		1.00	2
Hinge for Lid of Fertilizer Hopper20	4
Standards for Front of Fertilizer Hopper, Right or Left75	1
Standards for Rear " " " " "		.65	14
Brace for Front of Fertilizer Hopper55	1
Brace for Fertilizer Spouts25	10